





aeris


Quick Set Up Guide



airlite / 2 preinstalled filter
cable / sleeve / user manuals



flip airlite and plug in the cable.



Recommendations

Place the device at least 1m from walls and next to a potential leaking point (Windows).

Refrain from covering the air inlet or air outlet of the device.